

**LEEANN  
SHEER  
INSTALLATION  
INSTRUCTIONS**

**LEEANN SHEER  
INSTALLATION  
INSTRUCTIONS**

**1. UNPACKING**

The sheer fabric will be packaged separate from the vertical. When removing the plastic from the sheer, use caution as to not damage the sheer. Check that the edges of the PVC are rounded; this will ensure that the PVC does not snag the fabric during installation.

**2. INSTALLATION**

Install the vertical track and all PVC vanes. Then it is helpful to gather the sheer fabric over your shoulder. This will ensure that you take the weight of the fabric off the sewn hem during the installation of the first few vanes. Please note: It is not necessary to remove the vanes from the track to install Renaissance Sheers.

When the Renaissance Sheer is shipped to you all the snaps are attached to each other. It is very important that you unsnap the rear snap only, not the front snap. This will make the Renaissance Sheer easier to install. The front snap forms a small fabric pocket or ledge for you to position the sheer on the vane. Be sure the vertical vanes are in the open position.

To attach the sheer dapery to the vanes, begin with the first vane on the right side of the blind. Locate the first snap pocket on the right side of the sheer. Unsnap the back snap and wrap the sheer around the top of the vane. Connect the snap to complete.

Continue the same process for the balance of the vanes.

Insert the PVC vanes into their respective pockets at the bottom of the sheer. It is recommended that you bend the slat enough to allow for easy insertion into the pocket.

**3. CENTER OR SPLIT DRAW  
INSTALLATION**

On the draw sheers, the two center vanes are constructed to eliminate any light gap. Specifically, the two center sheer pockets have added pleats which overlap when drawn together in the open vane position. To ensure proper installation, locate the ends of the sheers with the extra pleat and position them in the center of the blind.

**4. VALANCE INSTALLATION**

The valance insert will be packaged together with the sheer. Slide the fabric into the Prestige Valance profile, wrapping around the returns. Any excess fabric may be trimmed.